

**Subpart 112.25—Emergency Systems Having an Automatic Starting Diesel Engine or Gas Turbine Driven Emergency Power Source as the Sole Emergency Power Source**

**§ 112.25-1 General.**

This subpart contains requirements applicable to emergency power installations having an automatic starting diesel engine or gas turbine driven emergency power source as the sole emergency power source.

**§ 112.25-3 Normal source for emergency loads.**

(a) The normal source for emergency loads must be the ship's service generating plant.

(b) The power from the ship's service generating plant for the emergency loads must be supplied to the emergency switchboard by an automatic transfer switch located at the emergency switchboard.

**§ 112.25-5 Failure of power from the normal source.**

If there is a reduction of potential of the normal source by 15 to 40 percent, the diesel engine or gas turbine driving the final emergency power source must start automatically with no load on the emergency power source.

**§ 112.25-10 Transfer of emergency loads.**

(a) When the potential of the final emergency source reaches 85 to 95 percent of normal value, the emergency loads under § 112.15-5 must transfer automatically to the final emergency power source and this transfer must be accomplished in no more than 45 seconds after failure of the normal source of power.

(b) When the potential from the normal source has been restored, the emergency loads must be manually or automatically transferred to the normal source, and the final emergency power source must be manually or automatically stopped.

**Subpart 112.30—Emergency Systems Having an Automatically Connected Storage Battery as the Sole Emergency Power Source**

**§ 112.30-1 General.**

This subpart contains requirements applicable to emergency power installations having an automatically connected storage battery as the sole emergency power source.

**§ 112.30-3 Normal source for emergency loads.**

(a) The normal source for emergency loads must be the ship's service generating plant.

(b) The power from the ship's service generating plant for the emergency loads must be supplied to the emergency loads through automatic transfer switches.

**§ 112.30-5 Transfer of emergency loads.**

If there is a reduction of potential of the normal source by 15 to 40 percent, the emergency loads under § 112.15-5 must transfer automatically from the normal source to the emergency power source.

**§ 112.30-10 Restoration of normal source potential.**

When the potential from the normal source is restored to 85 to 95 percent of its normal value, the emergency loads must transfer automatically to the normal source.

**Subpart 112.35—Manually Controlled Emergency Systems Having a Storage Battery or a Diesel Engine or Gas Turbine Driven Generator as the Sole Emergency Power Source**

**§ 112.35-1 General.**

This subpart contains requirements applicable to emergency power installations having a manually controlled storage battery, diesel engine, or gas turbine driven generator as the sole emergency power source.